

REPORT DOCUMENTATION PAGE				Form Approved OMB No. 0704-0188	
<p>Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing this collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports (0704-0188), 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to any penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number. <b>PLEASE DO NOT RETURN YOUR FORM TO THE ABOVE ADDRESS.</b></p>					
1. REPORT DATE (DD-MM-YYYY) April 2015		2. REPORT TYPE Briefing Charts		3. DATES COVERED (From - To) April 2015- June 2015	
4. TITLE AND SUBTITLE EFFECT OF IN-SITU CURE ON MEASUREMENT OF GLASS TRANSITION TEMPERATURES IN HIGH-TEMPERATURE THERMOSETTING POLYMERS				5a. CONTRACT NUMBER In-House	
				5b. GRANT NUMBER	
				5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)  Andrew J. Guenthner, Josiah T. Reams, Michael D. Ford, Kevin R. Lamison, and Joseph M. Mabry				5d. PROJECT NUMBER	
				5e. TASK NUMBER	
				5f. WORK UNIT NUMBER Q0BG	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES)  Air Force Research Laboratory (AFMC) AFRL/RQRP 10 E. Saturn Blvd. Edwards AFB CA 93524-7160				8. PERFORMING ORGANIZATION REPORT NO.	
9. SPONSORING / MONITORING AGENCY NAME(S) AND ADDRESS(ES) Air Force Research Laboratory (AFMC) AFRL/RQR 5 Pollux Drive Edwards AFB CA 93524-7048				10. SPONSOR/MONITOR'S ACRONYM(S)	
				11. SPONSOR/MONITOR'S REPORT NUMBER(S) <b>AFRL-RQ-ED-VG-2015-146</b>	
12. DISTRIBUTION / AVAILABILITY STATEMENT Distribution A: Approved for Public Release; Distribution Unlimited. PA#15279					
13. SUPPLEMENTARY NOTES Briefing charts presented at SAMPE Spring Meeting 2015 in Baltimore, MD; 20 May 2015.					
14. ABSTRACT Using the dicyanate ester of bisphenol E (also known as Primaset LECy), we have illustrated the difficulties inherent in measurement of the glass transition temperature of this high-temperature thermosetting polymer via dynamic mechanical analysis alone. These difficulties result from the residual cure of samples heated beyond their glass transition temperatures. Comparative DSC and oscillatory TMA studies carried out using a variety of cure conditions showed that simply increasing the heating rate did not suppress the residual cure, although in many cases it allowed the glass transition to become apparent before the onset of rapid residual cure. The results indicated that ensuring the reliability of dynamic mechanical measurements of the glass transition temperature is very difficult to accomplish without the knowledge of residual cure properties provided by methods such as DSC.					
15. SUBJECT TERMS					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT	18. NUMBER OF PAGES	19a. NAME OF RESPONSIBLE PERSON
a. REPORT	b. ABSTRACT	c. THIS PAGE			Joseph Mabry
Unclassified	Unclassified	Unclassified	SAR	22	19b. TELEPHONE NO (include area code) 661-275-5857



## **Effect of In-Situ Cure on Measurement of Glass Transition Temperatures in High-Temperature Thermosetting Polymers**

**Andrew J. Guenther,<sup>1</sup> Josiah T. Reams,<sup>2</sup> Michael D. Ford<sup>2</sup>,  
Kevin R. Lamison,<sup>2</sup> Joseph M. Mabry<sup>1</sup>**

<sup>1</sup> Air Force Research Laboratory, Aerospace Systems Directorate, Edwards AFB, CA

<sup>2</sup> ERC Incorporated, Edwards AFB, CA

**Presenter: Dr. Andrew Guenther**  
Air Force Research Laboratory  
[andrew.guenther@us.af.mil](mailto:andrew.guenther@us.af.mil)  
(661) 275-5769

**20 May 2015**



*DISTRIBUTION A: Approved for public release; distribution is unlimited.*



# Outline: The Effects of “Frozen” Chemistry



- Background: Importance of Conversion
- Progress in Conversion Measurement
- Difficulties in Glass Transition Temperature Measurement
- Solutions that Work (and Some that Do Not Work)


**Acknowledgement: Air Force Office of Scientific Research; AMG Group Members**







# Model High-Temperature Thermosetting Polymers: Cyanate Esters



Principal reaction:



Selectivity: 80% - > 98%

$\Delta H_f = -110 \text{ kJ / eq.}$

Conversion kinetics; Auto-catalytic  
(may be catalyzed)

Typical conversion rate: ~50%/hr  
(max) at 250 °C (uncatalyzed)


Extend of conversion: Limited to  $T_G =$   
 $T_{cure} + 30\text{-}60 \text{ }^\circ\text{C}$

- A single, known reaction predominates.
- Methods for assessing the extent of side reactions, and for minimizing side reactions, are known.
- The structure of even fully cured networks is easily analyzed and described quantitatively.
- Samples are easy to prepare in the laboratory; cure conditions are readily manipulated over a very wide range of rates.







# Cyanate Esters: Next-Generation High-Performance Composite Resin








# Cyanate Ester Networks: Defined by Composition and Conversion




from X. Sheng, M. Akinc, and M. R. Kessler, *J. Therm. Anal. Calorim.* **2008**, 93, 77-85 for EX-1510

“ESR255”



“LECy”




- In addition to glass transition temperature, many properties, such as density and water uptake, are mainly functions of conversion and monomer type.



# Conversion and $T_G$ Are Intrinsically Linked in Cyanate Esters



## Conversion



## $T_G$

- Under non-degrading conditions ( $T < 300\text{ }^{\circ}\text{C}$ ), if conversion changes, then the  $T_G$  must also change with it. If the  $T_G$  changes, then cure has occurred. The only observed changes should be increases over time!
- A measurement of conversion is a measurement of  $T_G$ . Measurements of conversion and  $T_G$  may be combined to yield a more precise estimate of both parameters.
- Any measurement that indicates a change in conversion, such as non-reversible heat flow in a DSC experiment, also measures the rate of change of  $T_G$ .
- The preceding statements are true for any thermosetting network that forms by a single reaction method and is not subject to degradation during measurement.






# Conversion by DSC: The Usual Way




## Typical Residual Cure



Even in samples with well-defined exotherms, there is ambiguity ...

## What about this case?



At high conversions, the typical approaches become impossible

- Current solution: live with absolute error of up to 0.05 in conversion by DSC, corresponding to predicted  $T_G$  uncertainty of 25 – 50 °C.






# Re-Scanning Shows the Limitations of Typical Baseline Approach




## Typical Residual Cure



Re-scanning shows us where the baseline is above  $T_G$ , how  $T_G$  shifts, how  $T_G$  is partly hidden, and where instability starts

- Better solution: use the re-scan as a baseline (Kessler group).

## What about this case?




... and it works at high conversions



# Building a Baseline from Re-Scanning




## Typical Residual Cure



Magnitudes of step change should match (roughly), shift in step change should fit diBenedetto equation

## What about this case?




... and the exact same algorithm works well with samples at high conversion

- Even better solution: use the re-scan + account for shift in  $T_g$  & instability (our idea).





# Estimating Uncertainties




- Uses – range of possible offset values (light red); range of possible instability corrections (orange); estimated error in slope of extrapolation in re-scan using 0.05 W/g expected size of step change (purple). These errors are assumed to be uncorrelated.




# Assessment of New Baseline Method



**Old Way: Re-scan with range of possible offsets = baseline**



**New Way**



- Uncatalyzed LECy with cure at 170 °C / 24 hr + post-cure from none to 240 °C for 1 hr.
- Old way predicts glass transition temp at full cure = 282 °C; new method predicts 312 °C, experiments show it is at least 304 °C .






# “Direct” Measurement of $T_g$ ?

LECy, catalyzed with 2 phr nonylphenol +  
160 ppm Cu as Cu(II)Acac

Cured at 150 °C for  
12 hours




- Oscillatory TMA done in accordance with typical procedure shows three peaks for this single-component system, one peak corresponds to an increase of stiffness.



# Corresponding DSC Trace

LECy, catalyzed with 2 phr nonylphenol +  
160 ppm Cu as Cu(II)Acac

Cured at 150 °C for  
12 hours



- Excess heat release above 175 °C indicates that the sample is undergoing cure.






# “Direct” Measurement of $T_G$ ?

LECy, catalyzed with 2 phr nonylphenol +  
160 ppm Cu as Cu(II)Acac

Cured at 150 °C for  
12 hours



- In the shaded region, the sample is undergoing cure, which means that the  $T_G$  is changing while an attempt is being made to measure it!




# Inferred OTMA $T_G$ from Conversion Measurements



LECy, catalyzed with 2 phr nonylphenol +  
160 ppm Cu as Cu(II)Acac

Cured at 150 °C for  
12 hours



- The darker green lines indicate the uncertainty limits for  $T_G$ . Main sources of uncertainty are DSC to OTMA correspondence, and effect of degradation. Note that  $T_G$  increases faster than the scan temperature.






# Why Not “Outrun” $T_G$ ?

$T_G$  instability # =

Sensitivity x Cure Rate


Heating Rate

*Turns out the cure rate tends to be proportional to the heating rate!*



Heating Rate  
(°C / min.)

— 2  
- - 10



Heating Rate  
(°C / min.)

— 2  
- - 10



- Residual cure tends to show the universality associated with activated rate processes, which means that a change in scan rate and a shift in temperature are functionally equivalent.
- As a result, the  $T_G$  instability number tends to be insensitive to heating rate. A faster heating rate only provides a head start in the race against cure.



# Even Very Rapid Scans Do Not Always Prevent *In-Situ* Cure (1)



Uncatalyzed LECy (ageing study), cured at 210 °C for 24 hrs



- In the 2010 sample, 10 °C / min. was a little too slow to prevent in-situ cure (the true  $T_G$  at about 240 °C) is visible as the “shoulder”.
- In the 2012 sample, the true  $T_G$  is no longer discernible.







# Even Very Rapid Scans Do Not Always Prevent *In-Situ* Cure (2)



Uncatalyzed LECy (unaged), cured at 210 °C for 24 hrs  
2014 – < 1 yr stored at 5 °C




- The DSC scan shows clearly that *in-situ* cure begins immediately after passing the true  $T_G$  at about 240 °C.
- Although the loss peak in the OTMA captures the true  $T_G$ , both the storage modulus and tan delta measurements are affected by *in-situ* cure. Thus, even 50 °C/min. is only just fast enough for the OTMA scan.




# A Fast DSC Scan Will Always Indicate the “As Cured” $T_G$




Uncatalyzed Samples; After Heating 210 °C for 24 hrs



50 °C / min. PT-30



50 °C / min. PT-30 / LECy  
(50/50)



50 °C / min. FlexCy/LECy  
(50/50)

- No cure means the  $T_G$  does not change, so the cannot have ever been in the “flat” part of the curve.
- Only a change as drastic as passing through  $T_G$  would cause such a rapid initiation of cure.
- $T_G$  values inferred in this manner are reproducible to within 5 °C; slower heating rates work well for samples with lower values of  $T_G$  at full cure.

DISTRIBUTION A: Approved for public release; distribution is unlimited.





# Summary

- In polycyanurate networks (and any other thermoset polymer network for which a single, path-independent cure mechanism exists), conversion and the glass transition temperature are intrinsically linked.
- With careful consideration of the physical properties of these networks, DSC methods can be utilized to measure conversions to within 1-2% at >80% conversion.
- Dynamic mechanical methods (especially at slow heating rates) will not measure the glass transition temperature of undercured networks correctly, due to *in-situ* cure.
- In many cases, *in-situ* cure and the resulting measurement issues cannot be avoided simply by choosing a more rapid heating rate.
- DSC methods (especially at rapid heating rates) appear to be best-suited for assessing “as cured” glass transition temperatures.

QUESTIONS?



**U.S. AIR FORCE**